

# Operating Instructions for LED Calendar (JB-76902)

## I. Functions

1. Year (hidden) , Month, Date, Hour, Minute, Week and Temperature
2. 12H / 24H are switchable
3. light intensity decreases from 10:00 PM to 6:59 AM ( next day)
4. Calenda ranger: Jan.01,2000 to 31<sup>st</sup> Dec, 2099

## II. Instructions

1. Buttons name:

A : to set or transfer B: to increase C: to reduce

### Time setting

- After connect with adaptor and connect with power, press button “A” to set the time and you will find “Year” flashing. Then press button “B”or”C” to adjust
- After finishing , press “A” again, you will find “Month” flashing and repress button “B”or”C” to adjust the month.
- Then, press “A” to get the date setting, press button “B”or”C” to adjust
- Follow this step, to select 12H or 24H, to set [Minute] in turn.

Special mark : In the process of setting, you can press “A” to quit .

And all of your setting are valid.

2. When the time display is normal, press “B” to select “24” or “12” display mode.

## III. Temperature:

1. display range: -20°C--50°C, accuracy :  $\pm 2^{\circ}\text{C}$

## הוראות הפעלה שעון ירח דגם 4938

### תכונות:

1. שנה (מוסתר), חודש, תאריך, שעה, דקה, שבוע וטמפרטורה
2. 12 שעות / 24 שעות ניתנות להחלפה
3. עוצמת האור יורדת משעה 22:00 עד 6:59 בבוקר (למחרת)
4. Calendar: ינואר 01,2000 עד 31 בדצמבר, 2099

### הוראות כיוון:

שמות הכפתורים:  
A מעבר לנתון הבא  
B הוסף  
C הורד

### כיוון ראשוני:

חבר מטען, לחץ על כפתור "A": שדה "שנה" יבהב. כוון מעלה/מטה בעזרת לחצן "B" או "C"  
לחץ שוב על "A": שדה "חודש" יבהב כוון מעלה/מטה בעזרת לחצן "B" או "C"  
לחץ שוב על "A", שדה "יום" יבהב כוון מעלה/מטה בעזרת לחצן "B" או "C"  
לחץ שוב על "A": בחר תצוגת 12 שעות או 24 שעות,

### טמפרטורה:

טווח תצוגה: -20°C עד 50°C, דיוק:  $\pm 2^\circ\text{C}$