

פד-משטח טעינה אלחוטי מבית Charge-it דגם CH-4412



מדריך למשתמש

אזהרה

אנא קראו ונהגו על פי כל ההוראות ואמצעי הבטיחות המפורטים להלן טרם השימוש במוצר זה. כשל בכך עשוי לגרום לפגיעה אישית חמורה ו/או לנזק לרכוש.

אמצעי בטיחות

- אין לחשוף מוצר זה למקורות חום (לבות להבה פתוחה או אור שמש ישיר).
 - אין לחשוף מוצר זה למים או לנוזלים. במידה ונוזל חודש לתוך המוצר, נתקו מיד את המוצר ממקור החשמל או ממכשיר חשמלי אחר.
 - אין לפרק או לבצע שינויים במוצר.
 - הימנעו מהפלת מוצר זה (או כל פגיעה קשה במוצר עשוי לגרום נזק למעגל החשמלי הפנימי).
 - במקרה הבלתי סביר של מצבים חריגים (כגון ריח מוזר, התחממות יתר, דליפה, שינוי בצבע וכו') הפסיקו את השימוש במוצר זה באופן מידי.
- הימנעו מניקיון מוצר זה בעזרת נוזלים או חומרים כימיים (השתמשו במטלית יבשה בלבד).
- השתמשו רק בחיבורים/באבזרים המצוינים על ידי היצרן.
 השליכו פריט זה כנדרש (אין להשליך אותו בפחי אשפה ואין לנסות ולשרוף אותו).
 - אין להשאיר מוצר זה ללא השגחה בזמן שהוא נמצא
 רשימוש או בזמן נועינה.
- השתמשו במתאם A/C מורשה (אינו כלול) לחיבור פריט זה.
- נתקו את הפריט ממתאם ה- A/C (אינו כלול) לאחר סיום
 השימוש בו.
 - מוצר זה אינו משחק: הרחיקו מהישג ידם של ילדים.
 - אין להטעין יותר ממכשיר 1 במקביל.
 - טעינה אלחוטית של מחשב לוח אינה מומלצת.
- יש להסיר מהטלפון לוחית מתכת או כל גוף מתכתי אחר
 שיפריע להצמדה מגנטית.

מדריך למשתמש

זהו פד-משטח הכולל תחנת טעינה. אנא עיינו במפרטים הטכניים ובמדריך למשתמש שלהלן.

מפרטים טכניים

מספר פריט: CH-4414 (CH-4414 מספר פריט: CH-4414 סל פולט (CH-441) חשמל: DC פולט (CH-440 מפר ביציאת (פלט) חשמל אלחוטי: DC פולט (O.8 אמפר ארזרים: כבל מיקת USB/USB ובאורב של 8.0 מטר.

מפת המוצר



לטעינה אלחוטית של מכשיר טלפון אלחוטי בעזרת פד משטח לעכבר

- הכניסו את יצאת המיקח USB של כבל הטעינה (כלול)
 לתוך שקע הכניסה (סמל ♣ של פד משטח העכבר לתוך שקע הכניסה (סמל של ♣ של פד משטח העכבר USB וא USB
- 2. נורית החיווי האדומה והכחולה יהבהבו פעם אחת במטרה לציין כי פד משטח העכבר מוכן לטעינה אלחוטית של מכשיר הטלפון החכם שלכם. מרכזו את המכשיר האלקטרוני שלכם מעל הסמל (((**)). נורית חיווי כחולה תישאר דלוקה בזמן טעינה של המכשיר שלכם ועשויה להישאר דלוקה לאחר שהמכשיר טעון במלואו. (שימו לב חלק ממכשיר הטלפון החכמים הכוללים יכולת אלחוטית

- משולבת יכולים לנטבל את טבית החיווי הכחולה שבפד משטח העכבר ברגע שהמכשיר טעוו במלואו).
- להפסקת הטעינה. הוציאו את המכשיר האלקטרוני שלכם מהסמל (((*))) שבפד משטח העכבר ונתקו את כבל הנועינה

ושימו לר:

רק מכשירי טלפוו חכמים המצוידים ביכולות טעינה אלחוטיות יכולים לעשות שימוש בטעינה האלחוטית של פד משנוח

*במידה ולא נטעו הזז את הטלפוו על משטח הטעינה

וודא שהכיסוי אינו עבה מדי או הסר את הכיסוי*

הצהרת FCC

מכשיר זה תואם את סעיף 15 של חוקי ה- FCC. הפעלת המכושיר בפופה לשני התנאים הראים: (1) חל איסור על מכשיר זה לגרום להפרעה מזיקה וגם

- (2) מכשיר זה חייב לקבל כל הפרעה מתקבלת. לרבות הפרעה שעשויה לגרום להפעלה לא רצויה של המכשיר.

שינויים או התאמות שלא עברו אישור ברור מהצד האחראי לתאימות המוצר. עלולים לבטל את סמכותו של המשתמש להפעיל את הציוד

ישים עלי

ומעלה. IPhone -IPhone X. iPhone 8, 8 Plus Samsung -Samsung S6 Edge Plus, S7/S7 Edge, מעלה S8/S8 Plus, S9, Note 7/8/9 Nokia - Nokia 8, Lumina830, Lumina920, במעלה Lumina930 Lumina1020 Lumina1520. LG- LG G3 I LG G6/G6 Plus

NOTE:

- only smartphones equipped with wireless charging capabilities
- are able to use the wireless charging of the mouse pad the wireless charging dock of mouse pad will activate only when it
 - the wireless charging dock of mouse pad will activate only when it is connected to a certified A/C adapter (not included)

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and
 (2)This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Applicable to:

IPhone -IPhone X, iPhone 8, 8 Plus and up Samsung -Samsung S6 Edge Plus , \$7/\$7 Edge, \$8/\$8 Plus,\$9, Note 7/8/9 and up

Nokia – Nokia 8, Lumina830, Lumina920, Lumina1020, Lumina1520, Lumina930 and up

LG- LG G3. LG G6/G6 Plus



Made in China

USER MANUAL

This is a vinyl mousepad with an integrated wireless charging dock. Please see below product specifications & user quide.

Specifications

Item No.: CH-4414
Power Input: DC 5V/1.2A
Wireless Power Output: DC 5V/0.8A
Accessories: 1 meter micro-LISB/LISB Cable

Product Man



To wirelessly charge a wireless enabled smartphone device using the mouse pad

- Make sure your smartphone has integrated wireless capability or is equipped with wireless charging adapter
- Insert the micro USB output of charging cable (included) into the input port (-Φ icon) of mouse pad & connect USB output of the cable to a certified wall adapter (not included).
- 3. The red & blue LED will flash note to indicate that the mouse pad is ready to wirelessly charge your smartphone. Center your electronic device over the e-elicion. A blue LED will remain lit while charging your device& may remain lit once fully charged. (NOTE: some smartphones with integrated writeses capability can deactivate the blue LED on the mouse pad once the device is fully charged.
- 4. To stop charging, remove your electronic device from the (k-4) icon on mouse pad and disconnect the charging cable.

Charge-it

WIRELESS CHARGING MOUSE PAD

CH-4414

WARNING

Please read and follow all of the instructions & safety precautions detailed below prior to using this product. Failure to do so may result in serious personal injury and / or property damage.

Safety Precautions

- Do not expose this product to heat sources (including open flame or direct sunlight)
- Do not expose this product to water or liquids. If liquid enters the product, immediately unplug the product from any connected power sources or devices.
- Do not disassemble or modify the product
- Avoid dropping this product (or any other heavy impact which might damage the internal circuit)
- In the unlikely event of any abnormalities (such as strange odor, overheating, leaking, color change, etc.), discontinue use immediately.
- Avoid cleaning this product using liquids or chemical substances (use dry cloth only)
- Only use attachments/accessories specified by the manufacturer
- Dispose of this item properly (do not dispose of it in trash receptacles and do not attempt to incinerate it)
- Do not leave this product unattended while it is in use or while
- it is being charged

 Use certified A/C adapter (not included) to connect this item.
- Disconnect the item from A/C adapter (not included) after use
- This product is not a toy: KEEP AWAY FROM CHILDREN
- Do not charge more than 1 device at the same time
 Wirelessly charging a tablet is not recommended
- It is recommended to remove smartphone cases when recharging your device as heavy cases may disrupt wireless charging capability