

## הוראות הפעלה וכיוון לשעון דיילי ZA-2546 עם סנסור להפעלת תאורת המסך

### כיוון ראשוני

- ◆ הכנס 2 סוללות AA בגב המכשיר (לא כלולות).
  - ◆ לחץ **MODE** למשך 2 שניות לכניסה למצב תכנות – הספרות 00 (day light saving) יהבהבו, לחץ **MODE** פעם נוספת לכניסה לתכנות השעון, מונה השעות יהבהב.
  - ◆ לחץ על לחצני ▲ ▼ עד לקבלת השעה הרצויה.
  - ◆ לחץ על **MODE** למעבר לתכנות השדות הבאים: הדקות, השנה, החודש, היום בחודש והשפה הרצויה – החלף GER ובחר ENG. (השעון יציג אוטומטית גם את היום בשבוע)
  - ◆ לחץ **MODE** ליציאה ממצב תכנות.
- \*לחזרה למצב כיוון ראשוני של השעון הוצא והכנס סוללות.

### תצוגת 12/24 שעות

במצב תצוגה רגיל לחץ ▲ למעבר בין תצוגת 12/24 שעות

### תצוגת טמפרטורה צ'לזיוס או פרנהייט

במצב תצוגה רגיל לחץ ▼ למעבר בין תצוגת C צ'לזיוס או F פרנהייט

### הפעלת תאורת מסך

במצב תצוגה רגיל העבר ידך מעל המכשיר, תאורת המסך תידלק לחמש שניות.

### שעון המעורר AL1

#### שלב 1 תכנות השעה

- ◆ לחץ AL1 למשך 2 שניות, מונה השעות יהבהב, כוון לשעה הרצויה ע"י לחצני ▲ ▼ לחץ על **MODE** למעבר לדקות וכוון ע"י לחצני ▲ ▼ לאחר שקבעת את השעה לחיצה על **MODE** פעמיים תחזיר את התצוגה למצב שעון.

#### שלב 2 הפעלת השעון המעורר

- ◆ להפעלת השעון המעורר לחץ על AL1 בגב השעון, תצוגת פעמון תופיע.
- ◆ לביטול השעון המעורר לחץ על AL1 בגב השעון, תצוגת פעמון תכבה.
- בזמן הצילצול ניתן להפסיק את הצילצול ולהפעיל נודניק ע"י העברת היד מעל לשעון.

### ביטול שעון מעורר

- ◆ לכיבוי השעון המעורר לחץ על לחצני AL1 או AL2 עד להעלמת שני הפעמונים מהתצוגה.

## The manual for DM3931 alarm clock

### Manual time setting

Press and hold MODE for 2 seconds. Run set the time manually.

The lcd display will blink,perform the mode switching by pressing MODE in the following sequence: Zone set---hour---minute---year---month---date---weekday language.---exit setting

At the lcd display blink Zone time, press UP and DOWN to set the zone time.

Press MODE- the hour display will blink

press UP and DOWN to set the hour.

Press MODE- the minute display will blink

press UP and DOWN to set the minute.

Press MODE- the year display will blink

press UP and DOWN to set the year.

Press MODE- the month display will blink

press UP and DOWN to set the month.

Press MODE- the date display will blink

press UP and DOWN to set the date.

Press MODE- the weekday language display will blink

press UP and DOWN to set the weekday language.

Press MODE exit setting mode.

After 30 second with no key pressed the clock will revert to normal time display.

### Setting the language of the weekday

The language of the weekday display can be set by pressing and holding MODE, Pls see the Manual time setting. The abbreviations of the different languages will appear one after another:

ENG for English GER for German FRA for French ITA for Italian NET fo Netherland  
ESP for Spanish DAN for Denmark. press MODE to revision language of the weekday, press UP  
or DOWN when the appropriate abbreviation appears. The abbreviation for the weekday will  
appear in the selected language.

### Setting 12 or 24 hour mode

At the conventional mode,Briefly press UP to switch between 12 hour mode (AM/PM) and 24  
hour mode.

### Setting temperature C/F mode

At the conventional mode,Briefly press DOWN to switch between temperature C/F.

### Setting Alarm1 and Snooze

Press and hold Alarm1 for 2 seconds.

The hour of the alarm display will blink.

Press UP and DOWN to set the hour.

Press MODE- the minute of the alarm display will blink.

Press UP and DOWN to set the minute.

Press MODE-exit setting mode

If the Alarm1 time have to change, Alarm1 will set itself functional mode and the the LCD will be display Alarm1 marking

At the conventional mode, Briefly press Alarm1 to on/off the Alarm1.

At the Alarm1 give an alarm mode, Briefly press SNOOZE/LIGHT to cut over snooze mode and the back light will lighten, Briefly press Alarm1 to stop Alarm noise.

#### Setting Alarm2 and Snooze

Press and hold Alarm2 for 2 seconds.

The hour of the alarm display will blink.

Press UP and DOWN to set the hour.

Press MODE- the minute of the alarm display will blink.

Press UP and DOWN to set the minute.

Press MODE-exit setting mode

If the Alarm2 time have to change, Alarm2 will set itself functional mode and the LCD will be display Alarm2 marking

At the conventional mode, Briefly press Alarm2 to on/off the Alarm2.

At the Alarm2 give an alarm mode, Briefly press SNOOZE/LIGHT to cut over snooze mode and the back light will lighten, Briefly press Alarm2 to stop Alarm noise.

#### Sensor infrared induction (Infrared sensing Control Snooze/backlight Button)

When the alarm is ring, put your hand to the clock to cut over snooze mode and the back light will Lighten.