

Charge-it HD WiFi Camera

Quick Start Guide

Model: CH-4533

Before using the product, please read the guide carefully to avoid any damages to the product in virtue of faulty operation or misuse.

1 Package List

Camera
USB cable
Power adapter
Screws
Quick Guide

※ The picture is only for reference and the real object shall prevail.

2 Appearance

Light sensor
Camera Lens
Pilot lamp
RESET (Press "RESET" button)
Micro TF card slot
DC5V power socket

3 Installation

Preparation for Installation

- 2.4G wireless router is required;
- Support Android 4.44 and above, IOS 9.0 and above;
- Downloaded APP: Please select one of below two methods to download the APP: then complete the installation and account registration.
 - A: Scan the QR code to download APP
 - B: Search the APP name "GOSCAM" on the Google play or App Store

Remark: The APP interface may be upgraded and adjusted at any time, subject to app as its actual basis without prior notice

4. Add a device: Open the APP home page click the "Add Device" icon to connect your camera. According to the settings guide in the APP, you can configure multiple cameras of the same time.

4 Connect to the power supply

- Find the power interface behind the product and power on the camera. The indicator will turn on.
- Please make sure the camera and smart phone are connecting to the same 2.4GHz band WiFi.

6 Operation

Register/Login

Step 1: Tap the "GOSCAM" APP icon to open it.
Step 2: Use email address for user ID registration (figure 2);
Step 3: After registration, enter the email address and then password to log in (figure 1)

TIP: For user ID registration, please use an effective email address, (example XXXX@gmail.com), in order to retrieve the password.

7 Technical Parameters

Resolution	1280*720P
Video Format	H.264
Wireless Transmission	802.11b/g/n 2.4GHz WiFi
Night Vision	Infrared
Remote Intercom	Two-way audio
Power Input	5V 1A
Alarms	Motion detection
Storage	Built-in Micro TF card slot, Max support 32GB
APP	Android 4.44 and above, IOS 9.0 and above
Working Standard	For indoor USE only
Working Temperature	-10C° - +50C°

※ All parameters change without prior notice. The final right of interpretation is reserved by the company.

FCC Certification Info

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, we declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

Notice: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU).

EU Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

PAP

CE FCC

Made in China

Front

Charge-it HD WiFi Camera

מצלמת HD WiFi

מדריך להתחלה מהירה

דגם: CH-4533

1 רשימת מרכיבי החבילה

מדריך הפעלה
ברגים
מאגנט השטל
כבל USB
התמונה להתחלה מהירה

2 נראות

חיישן אור
עדשת מצלמה
נורית
אתחול לחץ על כפתור האתחול
פתח כרטיס TF
שקע חשמל DC5V

3 מאפיינים טכניים

רזולוציה	1280*720P
סוגי קובץ וידאו	H.264
העברת הנתונים	802.11b/g/n 2.4GHz WiFi
צילום לילה	אדום-ירוק
איושן מרחוק	אודיו-וידאו
קלט חשמל	5V 1A
התראה	מאגנט חשמל מובנה, תאורת לילה
אחסון	אחסון מובנה
רשת	אדרויוד - 4.4 מעלה, IOS 9.0 מעלה
ספונדט הגנה	לשימוש פנימי בלבד
מחזור חיים	10000 שעות
טמפרטורת עבודה	50C° מעלה עד -10C°

4 התקנה

הכנה להקמה

- נעלה IOS 9.0 או מעלה, או IOS 4.4 מעלה, או אפילו IOS 9.0 מעלה
- הורדו את היישומון (אפליקציה) "GOSCAM" באחת משתי השוקות המפורסות מסך כדי להתחבר אל היישומון ולקבל את התחבולה
- אם היישומון אינו זמין, לחצו על ה-QR כדי להוריד את היישומון

התחבר לרשת

- התחבר אל כבל הרשת לחלק השמור
- בבד המצלמה והחזיקו את המצלמה
- אם ודאו כי המצלמה והחזיקו את המצלמה
- התחבר אל רשת ה-Wi-Fi

בקר (נורית לד) המצלמה

הבקר	מבצע על כבל החשמל
שקע חשמל	לרשת
הבקר	מבצע על מצלמת חיצונית
הבקר	המצלמה לרשת
הבקר הידוי	מבצע על חיצונית המצלמה
הבקר הידוי	מבצע על חיצונית המצלמה
הבקר הידוי	מבצע על חיצונית המצלמה
שקע חשמל	מבצע על חיצונית המצלמה

5 התחברו לאספקת החשמל

- התחבר אל כבל הרשת לחלק השמור
- בבד המצלמה והחזיקו את המצלמה
- אם ודאו כי המצלמה והחזיקו את המצלמה
- התחבר אל רשת ה-Wi-Fi

בקר (נורית לד) המצלמה

הבקר	מבצע על כבל החשמל
שקע חשמל	לרשת
הבקר	מבצע על מצלמת חיצונית
הבקר	המצלמה לרשת
הבקר הידוי	מבצע על חיצונית המצלמה
הבקר הידוי	מבצע על חיצונית המצלמה
הבקר הידוי	מבצע על חיצונית המצלמה
שקע חשמל	מבצע על חיצונית המצלמה

6 הפעלה

הרשמה / התחברות

שלב 1: לחצו על "הוסף מצלמה" ביישומון "GOSCAM" כדי להתחבר אל המצלמה. אם המצלמה אינה זמינה, לחצו על "הוסף מצלמה" כדי להוריד את היישומון. לחצו על "הוסף מצלמה" כדי להוריד את היישומון.

שלב 2: לאחר ההרשמה, הכניסו את התחבולה כדי להתחבר אל רשת ה-Wi-Fi.

שלב 3: לאחר ההרשמה, הכניסו את התחבולה כדי להתחבר אל רשת ה-Wi-Fi.

7 מידע על אשור FCC

הצהרה: התקנת המצלמה חייבת להיות בהתאמה לדרישות FCC. המצלמה אינה אמורה לגרום לנזק או הפרעה לציוד אחר. המצלמה אינה אמורה לגרום לנזק או הפרעה לציוד אחר.

המצלמה אינה אמורה לגרום לנזק או הפרעה לציוד אחר. המצלמה אינה אמורה לגרום לנזק או הפרעה לציוד אחר.

Back

1. Click "Add camera", scan the QR code on the camera then you will hear a "Beep" prompt tone if successful. Reading the prompt carefully and click next. (figure 3-5)