

USER MANUAL



Production description:

The wireless earphone is a high quality stereo wireless earphone which possesses wireless music and calling function. Appearance vogue, beautifully designed, easy to carry, suitable for household, outdoor travel and other places, enjoy music anytime and anywhere. Get rid of cable tie, combined with perfect sound let movement more freedom, happiness.

Function features:

【Wireless Play】 Support pairing wireless devices to play music such as mobile phone, tablet, TV.

【Hands-free calls】 Support for hands-free calls function, built-in high sensitive microphones, making phone calls have carefree to enjoy.

【Voice Prompt Coming Calls】 It will prompt the phone number when you have a coming call, it is more convenient.

【IOS Battery Display】 IOS mobile phone real-time


display the earphone battery, let you know the earphone battery.

【Smart Power-off】 At the searching match status, if without any match in 5 minutes the TWS earphone will automatically power off.

【Rechargeable Lithium Electricity】 The built-in rechargeable lithium battery, environmental protection, economical and practical.

【Intelligent Charging】 The voice prompt please charge when the battery is low, when full charge it will automatically cut off power to avoid battery charging too much to damage to the battery.

Function definition of product buttons and slot:



①②Multifunction button ③④Status Indicator Lamp

⑤⑥Built-in Mic ⑦Charging box

⑧Charging ports of the charging box

⑨Indicator lamp of the charging box battery capacity

①②Multifunction button:

At the Shutdown state, long press the button①and button② for 3 seconds to turn it on, the red and blue light of the left side and right side earphone flashing, long press the button ① and button ② for 3 seconds to turn it off, the indicator lamp goes off. When the left side earphone and right side earphone connected with each other, long press the button① or button②for 3 seconds, then can turn the TWS earphone off. When the wireless connected successfully, long press the button ① or button ② for 1 second and hear the beep means choose the next song. When listen to the music, short press the button ① or button ② means pause the music playing, short press again to play the music

again. When you have an incoming call, short press the button ① or button ② to answer the call, long press the button ① or button ② to reject the call, continue press two times will redial the last time phone number. Press the key ① or key ② three times in succession to open the Siri function of the iPhone.

⑦ **【Charging box】** : Put the TWS earphone into the corresponding R, L charging position of the charging box.

⑧ **【Micro USB Charging Port】** : Power input jack, can use the native USB cable for charging, or connect to the 5V output charger with standard Micro USB cable of mobile phone.

★★★ Wireless pairing operation method of the first time:

When the headset is removed from the charging box, it will automatically turn on and the left and right ears will be automatically paired in 15S. (If there is any

uncertainty, the left and right ears are not automatically paired in 15S, please press twice quickly on key ① or key ② can be paired). Then search for the corresponding Wireless device name on the mobile phone, click the Wireless device name on the mobile phone, and when heard "Connected", the headset and the mobile phone are successfully paired. After that, the blue light of the left earphone and the right earphone will flash once every 5 seconds. For subsequent use, the TWS and the phone will automatically connected with each other.

Method of Charging:

1. Charge for the TWS earphone: Put the earphone into the R, L charging position corresponding to the charging box, and the TWS earphone will be automatically charged. At this time, the blue indicator light of the charging box lights up, the red light of the left and right earphones keeps on, the red light is off when fully charged. The charging box power indicator is off

in 10 seconds after the left and right headphones are fully charged.

2.Charging for the charging box: Insert one end of the charging cable into the micro USB ports of the charging box, the other end of the charging cable connect to the standard 5V output charger, red light flashing when charging, red light will all keep on after full charged.

Low battery:

When there was a low voltage power, the machine will prompt " Low battery, please charge", and then will automatically shut down, please recharge in time at this time. If it is not to be used for a long time, charging one time every month at least, it can protect the battery and extend battery life.

Auto power off function:

At the searching match status, if without any match in 5 minutes, the TWS earphone will automatically

power off.

Reset:

When the earphone suddenly crashed, please long press the power button for 8s, the earphone will boots again and back to normal state.

Product performance parameters:

1. Wireless Version: 5.0
2. Operation Distance: 10m
3. Transmitting Power: Class 2
4. Frequency Range: 2.402 -2.480 GHz
5. Speaker: Ø10mm
6. Impedance: 32Ω
7. Rechargeable Lithium Battery : 50mAh*2
Rechargeable Lithium Battery : 380mAh
8. Single Use Time: 4 hours
9. Use Time With The Charging Box: 12hours
10. TWS Earphone Charging Time: 1 hour
11. Charging Box Charging Time: 2 hours

*** שיטת פעולת הצימוד האלחוטי בפעם הראשונה:

ברגע שמוציאים את האוזניות מתיבת הטעינה, הן יופעלו באופן אוטומטי ואוזנייה שמאל וימין יפעילו תהליך צימוד אוטומטי תוך 15 שניות. (במקרה של אי וודאות, אוזנייה שמאל וימין אינן עוברות פעולת צימוד אוטומטית תוך 15 שניות, אנא לחצו פעמיים במהירות על מקש (1) או על מקש (2) לצימוד). לאחר מכן חפשו אחר שם המכשיר האלחוטי התואם במכשיר הטלפון הנייד, הקליקו על שם המכשיר האלחוטי במכשיר הטלפון הנייד וברגע שנשמעת המילה "מחובר", הדבר מציינ כי האוזניות ומכשיר הטלפון הנייד עברו תהליך צימוד בהצלחה. לאחר מכן, הנורית הכחולה של האוזנייה השמאלית ושל האוזנייה הימנית תהבהב פעם אחת בכל 5 שניות. בשימוש חוזר האוזניות יתחברו באופן אוטומטי לטלפון.

סוללה חלשה:

ברגע שקיים הספק מתח נמוך, המכשיר יתריע "סוללה חלשה, נא להטעין", ולאחר מכן ייכבה באופן אוטומטי, אנא הטעינו בזמן בשלב זה. במידה ולא מתוכנן לעשות שימוש במכשיר למשך פרק זמן ארוך, יש להטעין פעם בחודש לכל הפחות והדבר יסייע בהגנה על הסוללה ובהארכת חיי הסוללה.

מדדי ביצוע של המוצר:

1. גרסה אלחוטית: 5.0
2. מרחק הפעלה: 10 מטרים
3. הספק שידור: דירוג 2
4. טווח תדרים: 2.402 - 2.480 GHz
5. רמקול: \varnothing 10 מ"מ
6. עכבה: 32Ω
7. סוללת ליתיום נטענת: 50mAh*2
8. סוללת ליתיום נטענת: 380mAh
9. זמן שימוש בודד: 4 שעות
10. זמן שימוש בעזרת תיבת הטעינה: 12 שעות
11. זמן טעינה של אוזניית TWS: שעה
11. זמן טעינה של תיבת הטעינה: שעתיים

טעינת האוזניות- חברו את אוזניות TWS לתוך
תאי הטעינה ימין, שמאל שבמארז הטעינה. בשלב
זה, נורית החיווי הכחולה של תיבת הטעינה
תידלק, הנורית האדומה של אוזניות שמאל וימין
ממשיכה לדלוק, הנורית האדומה תיכבה ברגע
שהאוזניות טעונות במלואן. נורית חיווי ההספק של
תיבת הטעינה תיכבה תוך 10 שניות לאחר
שאוזנייה שמאל וימין טעונות במלואן.

טעינת מארז הטעינה- במארז שקע טעינה מיקרו
USB (8) , ניתן לחבר את כבל USB לטעינה
בכל מקור USB, או למטען 5 וולט בעזרת הכבל
המצורף. נורית החיווי האדומה מהבהבת בזמן
טעינה, הנורית האדומה תישאר דלוקה לאחר
טעינה מלאה.

איפוס:

כאשר האוזנייה נכבית באופן פתאומי, אנא לחצו
על לחצן POWER במשך 8 שניות, האוזנייה
תאתחל את עצמה מחדש ותחזור למצב רגיל:

צימוד ראשוני

לצימוד-1 כשהאוזניות במצב כבוי, לחצו על לחצן (1) ועל לחצן (2) במשך 3 שניות להפעלת האוזניות, הנורית האדומה והכחולה שבאוזניות יהבהבו.

לכיבוי-1 לחצו על לחצן (1) ועל לחצן (2) במשך 3 שניות לכיבוי האוזניות, נורית החיווי תיכבה.

שמיעת מוסיקה-1 ברגע שהאוזניות האלחוטיות התחברו בהצלחה, לחצו על לחצן (1) או על לחצן (2) במשך שנייה אחת ותשמעו צליל ביפ המציין בפניכם שעליכם לבחור בשיר הבא.

בזמן האזנה למוסיקה, לחיצה קצרה על לחצן (1) או על לחצן (2) מציינת השהייה בנגינת המוסיקה, לחצו לחיצה קצרה פעם נוספת להשמעת המוסיקה בשנית.


דיבורית-1 כאשר יש לכם שיחה נכנסת, לחצו על לחצן (1) או על לחצן (2) למענה לשיחה הנכנסת, לחצו לחיצה ארוכה על לחצן (1) או על לחצן (2) לדחיית השיחה הנכנסת.

ניתן ללחוץ פעמיים על מקש (1) או על מקש (2) על מנת להפעיל חיוג חוזר למספר הטלפון שחויג בפעם האחרונה.

לחצו על מקש (1) או על מקש (2) שלוש פעמים ברציפות לפתיחת פונקציית Siri של מכשיר ה-iPhone.

טעינה חכמה-1 ההתראה הקולית מציינת להטעין ברגע שהסוללה חלשה, ברגע שהסוללה טעונה במלואה מקור הספק החשמל ינותק באופן אוטומטי וזאת על מנת למנוע נזק לסוללה בעקבות טעינת יתר שלה.

הכרת לחצני המוצר והמארז:



- (1) וגם (2) לחצן רב תכליתי
- (3) וגם (4) נורית חיווי מצבים
- (5) וגם (6) מיקרופון מובנה
- (7) מארז טעינה
- (8) שקע טעינה של מארז הטעינה
- (9) נורית חיווי של הסוללה של מארז הטעינה

תיאור המוצר:

האוזניות אלו הן אוזניות סטריאו אלחוטיות איכותיות הכוללות מוסיקה ודיבורית איכותית. אוזניות אופנתיות, עיצוב מהודר, פשוטות לשימוש וקלות לנשיאה, מתאימות לשימוש בתוך הבית, לנסיעות בחוץ ולמקומות אחרים. כך תיהנו ממוסיקה בכל רגע נתון ובכל מקום נתון. נוחות מירבית, בשילוב עם צליל.

מאפיינים:

מוסיקה – ניתן לצמד מכשירים אלחוטיים מגוון במיוחד כגון מכשיר טלפון נייד, מחשב לוח, טלוויזיה.

דיבורית - תומכת בפונקציית ניהול שיחות ללא שימוש בידיים, מיקרופונים מובנים בעלי דרגת רגישות גבוהה, מה שהופך את שיחות הטלפון להנאה ללא דאגה.

התראה קולית על שיחות נכנסות - האוזניות יתריעו בפניכם וישמיעו את מספר הטלפון ברגע שנכנסת שיחה.

[תצוגת סוללה IOS] – בחלק ממכשירי הטלפון ניתן יהיה לראות את מצב הסוללה של האוזניות בזמן אמת

מדריך למשתמש



תודה על שבחרתם באוזניות 206 TWS.
אנא קראו בקפידה את מדריך ההוראות טרם השימוש במוצר זה

