

אוזניות בלוטוס דגם 4532

מדריך למשתמש

כיצד לשייך

- א) לחצו על לחצן הפעלה / כיבוי, נורית חיווי כחולה תהבהב במשך 3 שניות. נורית חיווי LED תהבהב בצבע אדום וכחול.
הדבר מציין כי האוזניות נמצאות במצב שייך.
- ב) וודאו כי פונקציית בלוטוס מופעלת במכשירים שלכם, בחרו בשם בלוטוס של האוזניות שלכם **CH-4532** להתחברות.
נגינת מוסיקה: באפשרותכם להאזין למוסיקה באמצעות קישוריות אלחוטית.
לחצו לחיצה קצרה על **||/V-** לשיר הבא / לחצו לחיצה ארוכה להקטנת עוצמת הקול.
לחצן **Play/Pause** **||**
- לחצו לחיצה קצרה על לחצן **||/V-** לשיר הקודם / לחצו לחיצה ארוכה להגברת עוצמת הקול.

מצב שיחה נכנסת (call-in)

- לחצו על מקש **||** פעם אחת למענה לשיחת טלפון.
לחצו על לחצן **||** במשך 3 שניות לדחיית שיחת טלפון.

פונקציית נגן MP3

- הכניסו את כרטיס ה-TF שלכם עם שירים לתוך הפתח להכנסת כרטיסי TF באוזניות שלכם. לחצו על מקש M להחלפת מצב לנגן MP3.
מקש **||/V-** - לחצו לחיצה קצרה על מקש זה למעבר לשיר הבא / לחצו לחיצה ארוכה להקטנת עוצמת הקול.
מקש **+**: לחצו לחיצה קצרה על מקש זה למעבר לשיר הקודם / לחצו לחיצה ארוכה להגברת עוצמת הקול.

פונקציית רדיו FM

- לחצו על מקש M למעבר למצב FM
|| - לחצו על מקש PAUSE למעבר למצב חיפוש ערוצים אוטומטי.
||/V- - לחצו על מקש זה למעבר לערוץ הרדיו הבא / לחצו לחיצה ארוכה להגברת עוצמת הקול.
||/V+ - לחצו לחיצה קצרה על מקש זה למעבר לערוץ הרדיו הקודם / לחצו לחיצה ארוכה להגברת עוצמת הקול.

פונקציית אוזניות מחווטות

ניתנת לשימוש גם באמצעות חיבור של כבל AUX

4532 Bluetooth headphone user manual

How to pair

a) Press the on/off button, blue LED indicator will flash for 3 seconds. LED indicator will flash red & blue light

This means headphone is in pairing mode.

b) Make sure Bluetooth on your devices is on, select your headphone Bluetooth name **CH-4532** to connect

Music playback: You can listen to music through wireless connectivity

Short press ►►/▼-! for next song/Long press to reduce volume

Play/Pause ►||

Short press ►►/▼-! for previous song/ Long press to increase volume

Call-in Mode

Press ►|| key one time to answer phone call

Press ►|| for 3 seconds to reject phone call

MP3 Player Function

Put your TF card with songs into the headphone TF card port

Press the M key to change mode to MP3 player

►►/▼-! key short press for next song/Long press to reduce volume

+key Short press for previous song/Long press to increase volume

FM Radio Function

Press the M key to FM mode

►|| press pause key Automatic channel search mode

►►/▼-! short press for next radio channel/Long press reduce volume

◄◄/▼+! Short press for previous radio channel/Long press increase volume

Wired Headset Function

can also be used by connecting AUX cable