


Size: 127X180MM

סקירת המוצר



האבזרים הכלולים

1 כבל טעינת USB למחשב PC

סוללה נטענת משולבת

רמקול זה מופעל באמצעות סוללת ליתיום נטענת משולבת. הטעינה את הסוללה כדלהלן:

- הכניסו את כבל הטעינה לחור שקע ספק ה-DC 5 וולט/שקע מיקרו USB של המכשיר. חברו את תקע ה-USB לתוך מחשב ה-PC או למתאם AC/DC. הנורית הופכת לאדומה והסוללה נטענת.
- ברגע שהסוללה טעונה במלואה, הנורית האדומה נכבית.

שיוך דגם ZA-4125 למכשיר הטלפון הנייד או למכשיר אחר

הפעילו את מצב שיוך הרמקול בזמן שהוא במצב כבוי. לחצו על לחצן ההפעלה/כיבוי במשך כ-6 שניות עד שהנורית הכחולה מהבהבת באופן קבוע. כעת הרמקול מוכן לשיוך. תתת טלפון: למענה או לניתוק שיחת טלפון. תתת נגינה/השהיית נגינת מוסיקה

הערות וטיפים

- באפשרותכם ללחוץ על לחצן הטלפון פעמיים במהירות לחיגוזר של השיחה האחרונה שבוצעה ממנו

איתור תקלות

התופעות	הסיבות	הפתרונות
לא ניתן להפעיל את הרמקול	הסוללה ריקה	הטעינה את הסוללה
לא ניתן לשיוך את הרמקול	הרמקול כבר מופעל ואינו במצב שיוך	עיינו בחלק המדבר על "שיוך BTS-06 למכשיר הטלפון הנייד או למכשיר אחר".

מפרט טכני

תמיכת בלוטוס	3.0+EDR
טווח	10 מטרים
תדר שידור	2.4 גיגה הרץ
הספק	ספק DC 5 וולט/ 100~120 אמפר/לשעה
סוללה	סוללת ליתיום 3.7 וולט 400 אמפר/לשעה
זמן טעינה	קרוב ל-3 שעות
זמן הפעלה	קרוב ל-4 שעות
דרוג IP	IPx4
משקל יחידה	קרוב ל-0.1 ק"ג

רמקול סאב-מרין \ BlueTooth
3W SubMarine מוגן מים IPX4

מדריך למשתמש ZA-4125



תודה על שרכשתם את המוצר שלנו. אנו מקווים שתיהנו ממנו מאוד.

שים לב: המכשיר מוגן בפני פסטוף בלבד, רמת הגנה IPX4

הוראות בטיחות

קראו מדריך זה בקפידה טרם הפעלת המכשיר ושמרו מדריך זה אצלכם לעיון העתיד.

- הרחיקו את המכשיר מחום, מאור שמש ישיר ומקצוות חדים.
- הרחיקו את המכשיר מלהבות או פתוחות.
- אין להכניס חפצי מתכת לתוך המכשיר. סכנה לקצר חשמלי!
- למניעת מטען סטטי, אין לעשות שימוש במכשיר בתנאי מזג אוויר קיצוניים.
- אין לתקן את המכשיר בעצמכם אלא צרו קשר עם אדם מקצועי מוסמך לכך.

טיפים:

- אנא וודאו כי הרמקול במצב כבוי בזמן שאתם מנסים להפעיל מצב שיוך.
- הפעילו את מכשיר הטלפון הנייד שלכם והפעילו את פונקציית בלוטוס.
 - חפשו ברשימה את התקן בלוטוס ZA-4125 יופיע על הצג.
 - שייכו את המכשיר שלכם עם ZA-4125.
 - במידה ונדרשת סיסמא, הזינו את הסיסמא "0000".
- השלמתם את השיוך דגם ZA-4125 עם המכשיר שלכם,

טיפים:


ברגע שרמקול זה משויך ומחובר למכשיר הטלפון הנייד שלכם, בפעם הבאה שתפעילו רמקול זה, הוא יתחבר למכשיר הטלפון הנייד שלכם באופן אוטומטי ברגע שבלוטוס מופעל בטלפון הנייד שלכם.

תיאור לחצנים

- On/Off: להפעלה ולכיבוי המכשיר.
- ⏮: לחצו לחיצה קצרה על לחצן זה למעבר לשיר הקודם, לחצו לחיצה ארוכה להנמכת עוצמת הקול.
- ⏭: לחצו לחיצה קצרה על לחצן זה למעבר לשיר הבא, לחצו לחיצה ארוכה להגברת עוצמת הקול.

WATERPROOF BLUETOOTH
SHOWER SPEAKER

USER MANUAL




Thank you for choosing our product We hope you will enjoy it very much.

Safety Instructions

Read this manual carefully before putting the appliance into operation and keep this manual for future reference.

- Keep the device away from heat, direct sunlight and sharp edges.
- Keep the device away from naked flames.
- Do not insert any metal object into the device. Risk of short circuit!
- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not repair the unit yourself but contact an authorised specialist.

Product Overview



Accessories Included

1 pc USB charging cable

Charge Integrated Battery

This speaker is powered by integrated rechargeable lithium battery. Charge the battery as follows:

- Insert the charging cable into the DC 5V socket / micro USB port on the unit. Connect the USB plug into a PC or AC/DC adaptor. The LED indicator turns RED and the battery is being charged.
- When the battery is fully charged, the RED LED indicator goes out.

Pairing ZA-4125 to mobile phone or other device

Activate the speaker's pairing mode by when in power off mode, press and hold the on / off button for about 6 seconds until BLUE LED is flashing constantly. Now the speaker is ready for pairing.

Tips:

Please make sure the speaker is in power off mode When trying to activate the pairing mode.

- Turn on your mobile phone and activate the Bluetooth function.
- Search for Bluetooth devices. ZA-4125 will show up.
- Pair your device with ZA-4125. If password is needed, type in "0000". After ZA-4125 is paired with your device, connect it to your device.

Tips:

Once this speaker is paired and connected to your mobile phone, next time when you switch on this speaker, it will connect to your mobile phone automatically as long as the Bluetooth in your mobile phone is on.

Button Description

⏻ On/Off: To switch on or off the unit

⏮ Short press for the previous song, long press for turning down the volume.

⏭ Short press for the next song, long press for turning up the volume.

☎ Phone: To pick up or hang up a phone call

⏸ Play/Pause the music

Notes & tips

- You can press Phone button twice quickly to redial the last phone call

Troubleshooting

Symptoms	Causes	Solutions
Can not switch the speaker on	Battery empty	Charge the battery
Unable to pair the speaker	Speaker is already switched on, and it is not in pairing mode.	Refer to the section of "Pairing ZA-4125 to mobile phone or other device"

Technical Specifications

Bluetooth support:	3.0+EDR
Range:	10meters
Transmitting frequency:	2.4G Hz
Power supply:	DC5V/100-120mA
Battery:	3.7V 400mAh lithium
Charging time:	approx. 3 hours
Operating time:	approx. 4 hours
IP grade:	IPx4
Unit weight:	approx. 0.1kg

